

MONTERINGSANVISNING



ASSEMBLY INSTRUCTIONS

ROCK SOFFBORD RUNT

Art. nr 19906-328



Assembly instructions | Monteringsanvisning



88888-302 88888-302 88888-264 88888-302 88888-267 88888-264 88888-264 88888-264 88888-266

2020

VENTURE DESIGN
HOME & INTERIOR