




Don't lift/pull in the heating element  
or the support rods



Don't lift/pull in the tank cover



Lift/pull in the grill



If turned on the side to pull out the heater

